Cross Lock with T-40 bolt - Installation Instructions

For best results, we recommend cleaning all debris from p-traps & drain lines prior to installation by a competent plumbing or maintenance technician.

- Remove grated drain cover if present.
- Choose the appropriate gasket of the two provided in your kit that best fits the throat of the drain opening, and insert the gasket into the drain throat.
- Screw in Cross Strainer using pliers or channel locks.
- Once tightened, replace the grated drain cover
- Insert the T-40 bolt through the hole in the center of the drain, down into the Cross Strainer. This anchors the drain cover to the cross strainer.
- Hand tighten with a T-40 Torx security bit or T-handle tool.

Watch the video to learn how to measure for a cross strainer:

https://www.youtube.com/watch?v=NE52_zCJM8g

Watch the video to learn how to install a cross strainer:

https://www.youtube.com/watch?v=psc2_xS_6BE&t=1s